

A new advanced THOR 5th crash test dummy finite element model development representing small female occupant

Agenda

- 1. Background
- 2. Possible NCAP Tests
- 3. Differences towards THOR-50th
- 4. Overview
- 5. Instrumentation and Sensors
- 6. Biofidelity tests
- 7. Certification tests
- 8. Ribcage deformation in the sled
- 9. Sled comparison with HIII-5th
- 10. Outlook and roadmap
- 11. Conclusion




Background

- THOR 5th percentile female ATD (THOR-5F) is needed to represent the small female occupant group for restraint system development
- First THOR-5F prototype was built in the early 2000's
- Humanetics started its own THOR-5F development in 2014
- NHTSA awarded Humanetics a contract to develop a THOR-5F in 2015
- Final design decisions were made collectively through discussions between
 NHTSA and Humanetics
- LS-DYNA model 0.5 FE model available since January 2018
- NHTSA Biofidelity Ranking System (BioRank) 1.28 (good biofidelity)



Possible NCAP Tests







Differences towards THOR-50th




Head with honeycomb structure

Chest flesh with foam insert

Abdominal pressure twin sensors



Overview







Biofidelity Tests



Face bar impact (Biofidelity test)







Biofidelity Corridors —









Thorax impact (Biofidelity test)








Biofidelity Corridors — Test — FEA V0.5









Upper abdomen steering wheel impact (Biofidelity test)







Biofidelity Corridors —









Lower abdomen bar impact (Biofidelity test)







Biofidelity Corridors —






Test — FEA V0.5



Certification Tests



Certification test matrix



5 Full dummy tests10 Component tests


Torsion

15 Tests




Heel of Foot

Forehead Impact






Face Rigid Disk Impact







Neck Flexion






Neck Extension








Neck Lateral Flexion






Upper Thorax Impact






Lower Abdomen Impact






Knee Slider Impact





Ribcage deformation in the sled






Sled comparison with HIII5-th 靊 THOR-5th HIII-5th **Chest Deflection** HH3-05F Test THOR-05F Average of four IR-TRACC FE THOR-05F Upper Left IR-TRACC FE THOR-05F Upper Right IR-TRACC FE THOR-05F Lower Left IR-TRACC FE THOR-05F Lower Right IR-TRACC FE



HH3-05F FE



Content of Version 1.0

- Component testing and validation
- Material testing
- Any additional hardware changes and customer feedback
- Initial validation against one of the sled (we are planning tests at Autoliv early 2019)



Thank you very much for your attention

© 2018 Humanetics Innovative Solutions, Inc.

This presentation is the proprietary property of Humanetics Innovative Solutions, Inc; a registered company in Plymouth, Michigan, USA. The report includes confidential information. Disclosure, use, copying, or distribution of this information without the written authorization of Humanetics Innovative Solutions is prohibited.